


## INSTALLATION AND MAINTENANCE INSTRUCTIONS

### For Chemline 1/2" To 4" True Union Y Strainers

***Installation (for all sizes)***

1. Note direction of flow in piping, (there is a flow direction arrow clearly marked on the body (1) of the strainer). Install Y strainer with screen (2) directed downward (as shown in Assembly drawing CYS1 - 0).
2. Tighten bolts evenly (if using flanges) and in sequence, as shown below.



3. Do not over-tighten the cap nut (8) in the screen unit, it has no direct bearing on sealing.
4. Specifications


Size	Material	Temperature (C°)	Maximum Pressure (20°C) Mpa (kgf/cm <sup>3</sup> )	End Connection	Mesh
1/2" - 2"	U-PVC	0-50	1.0 Mpa (10.2)	Flange Socket	20
3" - 4"	U-PVC	0-50	0.6Mpa (6.1)	Threaded	20

---

**Installation and Maintenance Y Strainers cont.*****Maintenance***

Refer to **ASSEMBLY DRAWING CYS1 rev 0**. And proceed as follows.

1. Loosen the union nut (8) remove the split ring (6), cap O-ring (5), cap filter cage (3) and screen (2).
2. Clean the screen retainer (4) and screen (2) and replace if necessary.
3. Inspect O-rings and replace if worn.
4. To re-assemble strainer reverse steps 3 through 1.



PART	DESCRIPTION	QTY	MATERIAL
1	BODY	1	PVC
2	FILTER SCREEN	1	PVC, 316 SS
3	CAP/FILTER CAGE	1	PVC
4	SCREEN RETAINER	1	PVC
5	CAP O-RING	1	EPDM/VITON
6	SPLIT RING	1	PVC
7	END CONNECTOR	2	PVC
8	UNION NUT	3	PVC
9	UNION O-RING	2	EPDM/VITON

TITLE  
 CHEMICAL LINE Y STRAINERS

REFERENCE

SCALE	DATE	CHEMICAL LINE PLASTICS	DMG. NO.	REV
DR. BY			CYSJ	0
CHKD. BY				
APP. BY				

